



because clean matters.

BANK AND SAFE LOCKS

Rather than soaking and hand scrubbing lock assemblies that are filthy with dust, rust, coagulated oil and other debris, you can safely and quickly clean them with ultrasonics from L&R. Simply-

1. Place lock assembly into a Pyrex Beaker and cover with #112 Ammoniated Ultrasonic Instrument Cleaning Solution.
2. Place Beaker into a positioning cover or an L & R Ultrasonic Cleaning System half filled with Instrument Rinsing Solution and cavitate for 3-5 minutes.
3. Remove lock and rinse in Ultrasonic Cleaning System containing Instrument Rinsing Solution -- cavitate for 3-5 minutes (Double Boiler Fashion).
4. Remove, let dry, and lubricate tumblers.

EQUIPMENT NEEDED:

Machines, Accessories*: Q140 Ultrasonic Cleaning System with Timer, Positioning Cover, Beakers, Auxiliary Pan.

Solutions: #112 Ammoniated Ultrasonic Instrument Cleaning Solution (Product Code 188); Instrument Rinsing Solution (Product Code 194).

* Recommended Ultrasonic Cleaning System varies as to internal tank dimensions and volume of required cleaning.

Please contact an L&R sales specialist to help determine the correct size for your needs.

