



because clean matters.

CAMERA SHUTTER ASSEMBLIES AND GEAR TRAINS

Soaking, spraying, and hoping it will work, are no longer necessary. L&R Ultrasonic Systems will clean thoroughly and lubricate properly the shutter assemblies of all types of cameras and add years of useful service.

Simply-

1. Place shutter assembly into a Beaker or tank containing L&R Instrument Rinsing Solution (PC# 194).
2. Cavitate for 3 minutes. Remove and drain.
3. Place shutter assembly into Auxiliary Pan containing L&R Instrument Rinsing Solution, plus a small amount of Molybdenum Lubricating Powder.
4. Cavitate 3 minutes.
5. Remove and air dry.

EQUIPMENT NEEDED:

Machines, Accessories*: Q90 or Q140 Ultrasonic Cleaning System with Timer, Positioning Cover, Beakers, Auxiliary Pan, Basket. The specific machine needed will depend on the quantity of work that must be produced at one time. Full lines of accessories are available for each unit.

Solution: L&R Instrument Rinsing Solution (Product Code 194).

*Recommended Ultrasonic Cleaning System varies as to internal tank dimensions and volume of required cleaning.

