



because clean matters.

CIRCULAR KNIVES

Rather than soaking and hand scrubbing circular knives that are filthy with dust, rust, grease and other debris, you can safely and quickly clean with L & R Ultrasonic Cleaning Systems.

Simply-

1. Fill tank approximately 3/4 full with SF-50 Heavy Duty Solvent Free Degreaser Concentrate or Hydro-Sonic Cleaner Concentrate Non-Ammoniated, diluted per label directions.
2. Place blades in Basket and immerse in ultrasonic tank.
3. Cavitate for 3-10 minutes depending on how dirty the blades are.
4. Remove basket and rinse with warm water and dry with heat or warm air.

EQUIPMENT NEEDED:

Machines, Accessories*: Q140 Ultrasonic Cleaning System. The specific machine needed will depend on the quantity of work that must be produced at one time. A full line of accessories are available for each unit.

Solution: SF-50 Heavy Duty Solvent Free Degreaser Concentrate (Product Code 071); HydroSonic Cleaner Concentrate Non-Ammoniated (Product Code 110).

*Recommended Ultrasonic Cleaning System varies as to internal tank dimensions and volume of required cleaning.

