



**L&R Manufacturing Company**

577 Elm Street, P.O. Box 607, Kearny, New Jersey 07032-0607 USA

Phone: 201-991-5330, Fax: 201-991-5870

E-mail: [info@LRultrasonics.com](mailto:info@LRultrasonics.com), [www.Lrultrasonics.com](http://www.Lrultrasonics.com)

## **FISHING REELS**

Acid soaks and abrasive hand cleaning are a thing of the past now that L&R Ultrasonic Cleaning Systems are available. Simply-

1. Place disassembled parts in Basket and immerse in tank containing Hydro-Sonic Cleaning Solution Concentrate Non-Ammoniated or SF-50 Solvent-Free Degreaser Concentrate at the recommended dilution (see product label).
2. Cavitate 3-7 minutes, drain in basket.
3. Rinse well under warm tap water.
4. Air dry or dry using forced warm air.
5. Lubricate and reassemble.

If salt water corrosion is a problem, cavitate in L&R Hydro-Sonic Concentrate (Ammoniated) without heat and rinse with water. Dry thoroughly, lubricate and reassemble.

### **EQUIPMENT NEEDED:**

Machines, Accessories\*: Q90, S140, Q140 or 2014 Ultrasonic Cleaning System with Timer, Optional Heater\*\*, Basket, Auxiliary Pan.

Solutions: Hydro-Sonic Cleaning Solution Concentrate Non-Ammoniated (Product Code 110); SF-50 Solvent-Free Degreaser Concentrate (Product Code 71); Hydro-Sonic Cleaning Solution Concentrate (Product Code 201)

\*Recommended Ultrasonic Cleaning System varies as to internal tank dimensions and volume of required cleaning.

\*\*If using Hydro-Sonic Cleaning Solution Concentrate Non-Ammoniated or SF-50 Solvent Free Degreaser. Heater not available on 2014.

**APPLICATION BULLETIN #15**