



*because clean matters.*

## **LENSES** (after grinding and buffing)

After grinding and buffing lenses, but before heat treating for break resistance, insure yourself against any foreign residue being burned into the lenses. L&R Ultrasonic Cleaning Systems offer the most complete cleaning possible.

Simply-

1. Fill tank 1/2 to 3/4 full with Optical Cleaning Solution.
2. Place lenses in lens holder and immerse in solution. Cavitate for 2-3 minutes.
3. Remove, rinse thoroughly in water.
4. Dry thoroughly.

### **EQUIPMENT NEEDED:**

Machines, Accessories\*: Q90 Ultrasonic Cleaning System with Timer, Optional Heater, Auxiliary Pan, Basket.

Solutions: Optical Cleaning Solution Concentrate (PC 216).

\*Recommended Ultrasonic Cleaning System varies as to internal tank dimensions and volume of required cleaning.

