



*because clean matters.*

## PILL MARKING DIES

Archaic hand-scrubbing methods lose out to Ultrasonic Cleaning Systems by L&R. Fast, thorough and economical cleaning the easy way.

Simply-

1. Place rack of dies into tank containing properly diluted Aqualar #1 Cleaning Solution Concentrate or SF-50 Heavy Duty Solvent-Free Degreaser Concentrate (diluted per container directions).
2. Cavitate for 12 minutes.
3. Remove, rinse thoroughly with water.

### EQUIPMENT NEEDED:

Machines, Accessories\*: Q650 or S650 Ultrasonic Cleaning System with Timer, Optional Heater, Basket or Rack.

Solution: Aqualar #1 Cleaning Solution Concentrate (PC203); SF-50 Heavy Duty Solvent-Free Degreaser Conc. (PC071).

\*Recommended Ultrasonic Cleaning System varies as to internal tank dimensions and volume of required cleaning.

