



L&R Manufacturing Company

577 Elm Street, P.O. Box 607, Kearny, New Jersey 07032-0607 USA

Phone: 201-991-5330, Fax: 201-991-5870

E-mail: info@LRultrasonics.com, www.LRultrasonics.com

SCBA FACE MASKS AND OTHER COMPONENTS

Self Contained Breathing Apparatus (SCBA) face pieces and component parts are often fouled with smoke, dirt and grime. The proper L&R Ultrasonic Cleaning System and Solution will provide thorough cleaning of these items. Simply-

1. Place component parts into a stainless steel rack or basket.
2. Insert rack or basket into an L&R Ultrasonic Cleaning Machine filled with properly diluted L&R SCBA Ultrasonic Cleaning Solution Concentrate.
3. Cavitate for 7-10 minutes.
4. Rinse thoroughly with water and dry.

EQUIPMENT NEEDED:

Machines, Accessories*: S360, S650 or S1000 Ultrasonic Cleaning System with appropriate stainless steel rack or basket.

Solution: SCBA Ultrasonic Cleaning Solution Concentrate (PC 049)

* Recommended Ultrasonic Cleaning System varies as to internal tank dimensions and volume of required cleaning.