



because clean matters.

TACHOGRAPH, ODOMETERS, SPEEDOMETERS

Removing greases, gum sediments and oil residues is easy with Ultrasonic Cleaning Systems and solutions from L&R.

Simply-

1. Place instrument in Basket and place Basket into tank #1 containing #112 Ammoniated Ultrasonic Instrument Cleaning Solution or Power Nofome Instrument Cleaning Solution.
2. Cavitate 3-5 minutes.
3. Remove Basket and place into tank #2 containing Instrument Rinsing Solution.
4. Cavitate 3-5 minutes, drain and allow to air dry.

EQUIPMENT NEEDED:

Machines & Accessories*: Q360 or other Ultrasonic Cleaning System with Timer, Auxiliary Pan, Basket; or 7652 with Clean & Rinse Kit.

Solutions: #112 Ammoniated Ultrasonic Instrument Cleaning Solution (PC188); Power Nofome Instrument Cleaning Solution (PC185); Instrument Rinsing Solution (PC194).

*Recommended Ultrasonic Cleaning System varies as to internal tank dimensions and volume of required cleaning.

