



**L&R Manufacturing Company**  
577 Elm Street, P.O. Box 607, Kearny, New Jersey 07032-0607 USA  
Phone: 201-991-5330, Fax: 201-991-5870  
E-mail: info@LRultrasonics.com, www.LRultrasonics.com

## **TATOOING NEEDLES -- HUMANS**

Clean oxides and sulphides safely and quickly with L&R Ultrasonic Cleaning Systems and proper cleaning solutions. Simply-

1. Fill Q140 with appropriate dilution of General Purpose Cleaner Concentrate, Ammoniated, to within one inch of top of tank.
2. Carefully place needle assembly in Basket. Do not allow needle tips to touch tank bottom.
3. Cavitate for 6 minutes.
4. Rinse thoroughly in water.
5. Dry and sterilize.

### **EQUIPMENT NEEDED:**

Machines, Accessories\*: Q140 or S140 Ultrasonic Cleaning System with Timer, Basket.

Solution: General Purpose Cleaner Concentrate, Ammoniated  
(Product Code 226)

\*Recommended Ultrasonic Cleaning System varies as to internal tank dimensions and volume of required cleaning.

**APPLICATION BULLETIN #42**