



*because clean matters.*

## TOUCHTONE CONTROLS

Now, instead of scrubbing touchtone controls by hand, all you need to do is place them in an L&R Ultrasonic Cleaning system and flip the switch. Then sit back and watch the machine do the work for you.

Simply-

1. Fill the first tank about 3/4 full with #222 Non-Ammoniated Ultrasonic Instrument Cleaning Solution.
2. Place the Basket containing parts (numbers down) in the first tank and cavitate 6-12 minutes.
3. Lift Basket and place into second tank containing Instrument Rinsing Solution and cavitate 6-12 minutes.
4. Remove parts and air dry.

### EQUIPMENT NEEDED:

Machines & Accessories\*: Q210 Ultrasonic Cleaning System with Timer, Basket, Auxiliary Pan.

Solutions: #222 Non-Ammoniated Ultrasonic Instrument Cleaning Solution (PC191); or Instrument Rinsing Solution (PC194).

\*Recommended Ultrasonic Cleaning System varies as to internal tank dimensions and volume of required cleaning.

