



*because clean matters.*

## Corona Wire Assembly Cleaning

Rather than wiping each wire manually with a cotton swab and alcohol, which is labor intensive and yields inconsistent results,

Simply-

1. Place assemblies on rack, or in basket, in a horizontal position and place in an L&R heated ultrasonic cleaning system of suitable size containing a solution of 2 ounces of Prep Clean Buffing Compound Remover Concentrate per gallon of 130°-140°F water. Clean for 2-3 minutes.
2. Remove rack or basket, let drain and rinse with hot water.
3. Remove and dry with heat gun or drying oven.

### EQUIPMENT NEEDED:

Machines, Accessories\*: Q210, Q310, S200 or S310 Ultrasonic Cleaning System with Timer, Optional Heater, Rack or Basket.

Solutions: Prep Clean Buffing Compound Remover Concentrate (PC078).

\*Recommended Ultrasonic Cleaning System varies as to internal tank dimensions and volume of required cleaning.

