



because clean matters.

ELECTRIC DEMAND METERS

Oil residues, gum sediments and grease are easily removed from electric meters adding years of life and accuracy. Non-abrasive cleaning with L&R Ultrasonic Cleaning Systems save hours of hand cleaning.

Simply-

1. Place in Basket and immerse in tank containing Hydro-Sonic Cleaning Solution Concentrate Non-Ammoniated, or SF-50 Solvent-Free Heavy Duty at the recommended dilution rates (see product labels).
2. Cavitate 5-10 minutes.
3. Rinse well under warm tap water.
4. Air dry or dry using warm air (forced air dryer).

EQUIPMENT NEEDED:

Machines, Accessories*: Q140 Ultrasonic Cleaning with Timer, Optional Heater**, Auxiliary Pans, Cover, Basket.

Solution: Hydro-Sonic Cleaning Solution Concentrate Non-Ammoniated (Product Code 110); SF-50 Heavy Duty Solvent-Free Degreaser Concentrate (Product Code 071).

*Recommended Ultrasonic Cleaning System varies as to internal tank dimensions and volume of required cleaning.

