



APPLICATION BULLETIN #5

CAMERA SHUTTER ASSEMBLIES AND GEAR TRAINS

Soaking, spraying, and hoping it will work, are no longer necessary. L&R Ultrasonic Systems will clean thoroughly and lubricate properly the shutter assemblies of all types of cameras and add years of useful service.

Simply-

1. Place shutter assembly into a Beaker or tank containing L&R Instrument Rinsing Solution (PC# 194).
2. Cavitate for 5 minutes. Remove, drain and air dry.

EQUIPMENT NEEDED:

Machines, Accessories*: Q90 or Q140 Ultrasonic Cleaning System with Timer, Positioning Cover, Beakers, Auxiliary Pan, Basket. The specific machine needed will depend on the quantity of work that must be produced at one time. Full lines of accessories are available for each unit.

Solution: L&R Instrument Rinsing Solution (PC194).

*Recommended Ultrasonic Cleaning System varies as to internal tank dimensions and volume of required cleaning.



because clean matters

L&R Manufacturing Company
577 Elm Street, PO Box 607
Kearny, NJ 07032-0607 USA
Tel: 201.991.5330 Fax: 201.991.5870
www.LRultrasonics.com info@LRultrasonics.com