



## APPLICATION BULLETIN #6

### CIRCULAR KNIVES

Rather than soaking and hand scrubbing circular knives that are filthy with dust, rust, grease and other debris, you can safely and quickly clean with L & R Ultrasonic Cleaning Systems.

Simply-

1. Fill tank approximately 3/4 full with SF-50 Heavy Duty Solvent Free Degreaser Concentrate or Hydro-Sonic Cleaner Concentrate Non-Ammoniated, diluted per label directions.
2. Place blades in Accessory Basket and immerse in ultrasonic tank.
3. Cavitate for 5-10 minutes depending on how dirty the blades are.
4. Remove basket and rinse with warm water and dry with heat or compressed air.

#### EQUIPMENT NEEDED:

Machines, Accessories\*: Q140 Ultrasonic Cleaning System. The specific machine needed will depend on the quantity of work that must be produced at one time. A full line of accessories are available for each unit.

Solution: SF-50 Heavy Duty Solvent Free Degreaser Concentrate (PC071)  
HydroSonic Cleaner Concentrate Non-Ammoniated (PC110)

\*Recommended Ultrasonic Cleaning System varies as to internal tank dimensions and volume of required cleaning.



*because clean matters*

L&R Manufacturing Company  
577 Elm Street, PO Box 607  
Kearny, NJ 07032-0607 USA  
Tel: 201.991.5330 Fax: 201.991.5870  
[www.LRultrasonics.com](http://www.LRultrasonics.com) [info@LRultrasonics.com](mailto:info@LRultrasonics.com)