



APPLICATION BULLETIN #8

CONDUCTIVE GLASS, DIGITAL READ-OUT WINDOWS

Cutting waxes and oils, lint, fingerprints and shop soil must be removed where accurate readings are desired. L&R Ultrasonic Cleaning Systems provide the thorough and fast cleaning necessary.

Simply-

1. Place rack or batch of glass windows into tank filled with General Purpose Cleaner Non-Ammoniated, Hydro-Sonic Cleaning Solution Concentrate, Hydro-Sonic Cleaning Solution Concentrate Non-Ammoniated or SF-50 Heavy Duty Solvent Free Degreaser Concentrate (solution depends on contamination present.)
2. Cavitate for 5 minutes.
3. Rinse thoroughly using distilled water.

EQUIPMENT NEEDED:

Machines, Accessories*: Quantrex Ultrasonic Cleaning System with Timer, Basket or Rack. The specific machine needed will depend on the quantity of work that must be produced at one time. Full lines of accessories are available for each unit.

Solutions: General Purpose Cleaner Non-Ammoniated (PC228)
Hydro-Sonic Cleaning Solution Concentrate (PC201)
Hydro-Sonic Cleaning Solution Concentrate Non-Ammoniated (PC110)
SF-50 Heavy Duty Solvent Free Degreaser Concentrate (PC071)

*Recommended Ultrasonic Cleaning System varies as to internal tank dimensions and volume of required cleaning.



because clean matters

L&R Manufacturing Company
577 Elm Street, PO Box 607
Kearny, NJ 07032-0607 USA
Tel: 201.991.5330 Fax: 201.991.5870
www.LRultrasonics.com info@LRultrasonics.com