



APPLICATION BULLETIN #60

Corona Wire Assembly Cleaning

Rather than wiping each wire manually with a cotton swab and alcohol, which is labor intensive and yields inconsistent results,

Simply-

1. Place assemblies in basket, in a horizontal position and place in an L&R heated ultrasonic cleaning system of suitable size containing a solution of 2 ounces of Prep Clean Buffing Compound Remover Concentrate per gallon of 130°-140°F water. Clean for 5 minutes.
2. Remove rack or basket, let drain and rinse with hot water.
3. Remove and dry with heat gun or drying oven.

EQUIPMENT NEEDED:

Machines, Accessories*: Q210, Q310, S200 Ultrasonic Cleaning System with Timer, Optional Heater, Basket.

Solutions: Prep Clean Buffing Compound Remover Concentrate(PC078)

*Recommended Ultrasonic Cleaning System varies as to internal tank dimensions and volume of required cleaning.



because clean matters

L&R Manufacturing Company
577 Elm Street, PO Box 607
Kearny, NJ 07032-0607 USA
Tel: 201.991.5330 Fax: 201.991.5870
www.LRultrasonics.com info@LRultrasonics.com