



## APPLICATION BULLETIN #15

### FISHING REELS

Acid soaks and abrasive hand cleaning are a thing of the past now that L&R Ultrasonic Cleaning Systems are available.

Simply-

1. Place disassembled parts in Basket and immerse in tank containing Hydro-Sonic Cleaning Solution Concentrate Non-Ammoniated or SF-50 Solvent-Free Degreaser Concentrate at the recommended dilution (see product label).
2. Cavitate 5-10 minutes, drain in basket.
3. Rinse well under warm tap water.
4. Air dry or dry using forced warm air or compressed air.
5. Lubricate and reassemble.

If salt water corrosion is a problem, cavitate in L&R Hydro-Sonic Concentrate (Ammoniated) without heat and rinse with water. Dry thoroughly, lubricate and reassemble.

#### EQUIPMENT NEEDED:

Machines, Accessories\*: Q90, Q140 Ultrasonic Cleaning System with Timer, Optional Heater\*\*, Basket

Solutions: Hydro-Sonic Cleaning Solution Concentrate Non-Ammoniated (PC110)  
SF-50 Solvent-Free Degreaser Concentrate (PC71)  
Hydro-Sonic Cleaning Solution Concentrate (PC201)

\*Recommended Ultrasonic Cleaning System varies as to internal tank dimensions and volume of required cleaning.

\*\*If using Hydro-Sonic Cleaning Solution Concentrate Non-Ammoniated or SF-50 Solvent Free Degreaser.



*because clean matters*

L&R Manufacturing Company  
577 Elm Street, PO Box 607  
Kearny, NJ 07032-0607 USA  
Tel: 201.991.5330 Fax: 201.991.5870  
[www.LRultrasonics.com](http://www.LRultrasonics.com) [info@LRultrasonics.com](mailto:info@LRultrasonics.com)