



APPLICATION BULLETIN #16

FUEL FILTERS (AIRCRAFT)

Soaking fuel filters in highly flammable Stoddard Solvent is DANGEROUS and time consuming. A better approach is to use an L&R Ultrasonic Cleaning System.

Simply-

1. Place Basket containing filters into tank filled 2/3 with Hydro-Sonic Cleaning Solution Concentrate or Hydro-Sonic Cleaning Solution Concentrate Non-Ammoniated at the recommended dilution (see product labels).
2. Cavitate 5-10 minutes.
3. Remove and rinse well under warm tap water.
4. Air dry or dry using warm forced air or compressed air.
5. Purge with fuel to displace traces of water before using.

EQUIPMENT NEEDED:

Machines, Accessories*: Q210 Ultrasonic Cleaning System with Timer, and Basket (optional heat)

Solutions: Hydro-Sonic Cleaning Solution Concentrate(PC201)
Hydro-Sonic Cleaning Solution Concentrate Non-Ammoniated (PC110)

*Recommended Ultrasonic Cleaning System varies as to internal tank dimensions and volume of required cleaning.

**Please contact an L&R Sales Specialist to discuss appropriate size machine for cleaning of multiple parts at one time.



because clean matters

L&R Manufacturing Company
577 Elm Street, PO Box 607
Kearny, NJ 07032-0607 USA
Tel: 201.991.5330 Fax: 201.991.5870
www.LRultrasonics.com info@LRultrasonics.com