



## APPLICATION BULLETIN #20

### GOLD AND JEWELRY

Rather than boiling, steaming, and brushing polishes, flux, solder residue, and rouges etc. from just-manufactured jewelry, you can safely and quickly clean with ultrasonic equipment from L&R.

Simply-

1. Place rack of rings (or other jewelry) into an approximately sized L&R Ultrasonic Cleaner filled 2/3 with proper dilution of Ellanar Jewelry Cleaner Concentrate or PrepClean Buffing Compound Remover (see label for typical dilutions).
2. Cavitate 5-10 minutes.
3. Rinse with water or steam.

#### EQUIPMENT NEEDED:

Machines, Accessories\*: Q90, Q140, Q210, Q360, Q650, or 4000 Series Ultrasonic Cleaning System of appropriate size, with Timer, Optional Heater\*\*, Basket

Solutions: Ellanar Jewelry Cleaner Concentrate (PC170)  
PrepClean Buffing Compound Remover (PC078)

\*Recommended Ultrasonic Cleaning System varies as to internal tank dimensions and volume of required cleaning.

\*\*Note: Do not use internal heater when using Ellanar Jewelry Cleaner Concentrate, Ammoniated, as this will cause release of excessive ammonia.



*because clean matters*

L&R Manufacturing Company  
577 Elm Street, PO Box 607  
Kearny, NJ 07032-0607 USA  
Tel: 201.991.5330 Fax: 201.991.5870  
[www.LRultrasonics.com](http://www.LRultrasonics.com) [info@LRultrasonics.com](mailto:info@LRultrasonics.com)