



## APPLICATION BULLETIN # 62

### HANDCUFFS

Handcuffs can be cleaned, disinfected, lubricated and protected from corrosion with the Cuff Pro Ultra Cleaning System.

Simply-

1. Fill the tank of the Quantrex 2/3 with water. Remove cap from unit, close chamber of UltraDose Germicidal and gently squeeze bottle filling to ½ oz. line. Pour into tank.
2. Degas for 5 minutes.
3. Place handcuffs in the accessory basket and put in tank. For best results leave handcuffs in the open position.
4. Place cover on top and turn unit on. Set timer for a 10 minute cleaning cycle.
5. Once cleaning cycle is complete, remove the basket and rinse the cuffs while in the basket under tap water. Shake off any residual water left on the cuffs.
6. Spray handcuffs with Barrier Milk Ready to Use Spray to lubricate and prevent rust. Special attention should be given to joints and locking mechanism.
7. Wipe with dry cloth.

#### EQUIPMENT NEEDED:

Machines, Accessories:

Cuff Pro Ultra Cleaning System, HCS 200  
Dual System, Quantrex with Basket &  
Auxiliary Pan

Solutions:

UltraDose Germicidal (PC UD036), Barrier  
Milk Ready to Use Spray (PC 00139), Barrier  
Milk Gallon (PC 076)



*because clean matters*

L&R Manufacturing Company  
577 Elm Street, PO Box 607  
Kearny, NJ 07032-0607 USA  
Tel: 201.991.5330 Fax: 201.991.5870  
[www.LRultrasonics.com](http://www.LRultrasonics.com) [info@LRultrasonics.com](mailto:info@LRultrasonics.com)