



## APPLICATION BULLETIN #23

### LENSES (after grinding and buffing)

After grinding and buffing lenses, but before heat treating for break resistance, insure yourself against any foreign residue being burned into the lenses. L&R Ultrasonic Cleaning Systems offer the most complete cleaning possible.

Simply-

1. Fill tank 2/3 full with UltraDose Ultrasonic Cleaning Solution - properly diluted.
2. Place lenses in lens holder and immerse in solution. Cavitate for 5 minutes.
3. Remove, rinse thoroughly in water.
4. Dry thoroughly.

#### EQUIPMENT NEEDED:

Machines, Accessories\*: Q90 Ultrasonic Cleaning System with Timer, Optional Heater, Basket.

Solutions: UltraDose Ultrasonic Cleaning Solution (PC012).

\*Recommended Ultrasonic Cleaning System varies as to internal tank dimensions and volume of required cleaning.



*because clean matters*

L&R Manufacturing Company  
577 Elm Street, PO Box 607  
Kearny, NJ 07032-0607 USA  
Tel: 201.991.5330 Fax: 201.991.5870  
[www.LRultrasonics.com](http://www.LRultrasonics.com) [info@LRultrasonics.com](mailto:info@LRultrasonics.com)