



APPLICATION BULLETIN #25

MOBILE COMMUNICATION SETS

3-Way radios, handsets, walkie-talkie sets, etc. need no longer be sent to the manufacturer for rehabilitation. Dirt, dust, rust, and oxidation can be removed quickly, safely, and thoroughly with an L&R Ultrasonic Cleaning System.

Simply-

1. Remove housing before cleaning.
2. Place entire set into Basket and put into tank #1 containing #222 Non-Ammoniated Ultrasonic Instrument Cleaning Solution.
3. Cavitate 5 minutes. Lift out and let drain (60 seconds).
4. Immerse Basket into Auxiliary Pan containing L&R Instrument Rinsing Solution.
5. Cavitate 5 minutes. Lift out and drain. Air dry.
6. Test and reinstall.

EQUIPMENT NEEDED:

Machines, Accessories*: Q210, Q360 or S200 Ultrasonic Cleaning Systems, Timer, Auxiliary Pan, Basket

Solutions: #222 Non-Ammoniated Ultrasonic Cleaning Solution (PC191)
Instrument Rinsing Solution (PC194)

*Recommended Ultrasonic Cleaning System varies as to internal tank dimensions and volume of required cleaning.



because clean matters

L&R Manufacturing Company
577 Elm Street, PO Box 607
Kearny, NJ 07032-0607 USA
Tel: 201.991.5330 Fax: 201.991.5870
www.LRultrasonics.com info@LRultrasonics.com