



APPLICATION BULLETIN #26

MODEL RAILROAD EQUIPMENT - CLEANING

Hand cleaning of disassembled parts is no longer necessary. Faster, more effective cleaning of fully-assembled pieces is now possible with L&R Ultrasonic Cleaning Systems.

Simply-

1. Place Basket with part to be cleaned into tank containing #222 Non-Ammoniated Ultrasonic Instrument Cleaning Solution.
2. Cavitate 3-5 minutes. Remove Basket, let drain.
3. Place Basket into Auxiliary Pan filled with Instrument Rinsing Solution. Place pan into main tank (double boiler fashion), so liquid in main tank makes contact with bottom of Auxiliary Pan.
4. Cavitate 3-5 minutes. Remove Basket, let drain.
5. Run on test track. Lubricate.

Note: Unpainted brass parts may be prepared for painting by using the exact same procedure.

EQUIPMENT NEEDED:

Machines, Accessories*: Q140, Q210 or S200 Ultrasonic Cleaning Systems with Timer, Basket, Auxiliary Pan.

Solutions: #222 Non-Ammoniated Ultrasonic Instrument Cleaning Solution (PC191)
Instrument Rinsing Solution (PC194)

*Recommended Ultrasonic Cleaning System varies as to internal tank dimensions and volume of required cleaning.



because clean matters

L&R Manufacturing Company
577 Elm Street, PO Box 607
Kearny, NJ 07032-0607 USA
Tel: 201.991.5330 Fax: 201.991.5870
www.LRultrasonics.com info@LRultrasonics.com