



APPLICATION BULLETIN #39

SCBA FACE MASKS AND OTHER COMPONENTS

Self-Contained Breathing Apparatus (SCBA) face pieces and component parts are often fouled with smoke, dirt and grime. The proper L&R Ultrasonic Cleaning System and cleaner will provide thorough cleaning of these supplies.

Simply-

1. Place component parts into a stainless steel rack or basket.
2. Insert rack or basket into an L&R Ultrasonic Cleaning Machine filled with properly diluted cleaner.* Add 1 packet of L&R's PCN #00219 Water Flakes Powdered Detergent/Disinfectant cleaner to each gallon of warm water.
3. Cavitate for 10 minutes. Do not heat above 120F to avoid the risk of distorting certain plastics.
4. Rinse thoroughly with water and dry.

Equipment Needed:

Machines, Accessories**: S360, Q650 or S1000 Ultrasonic Cleaning System
With appropriate stainless steel rack or basket.

Solution: Water Flakes Powdered Detergent/Disinfectant
(PC0129)

*Once diluted with water you have 30 days to use the solution. Discard solution if it is turbid or does not appear acceptable.

**Recommended Ultrasonic Cleaning System varies as to internal tank dimensions and volume of required cleaning.



because clean matters

L&R Manufacturing Company
577 Elm Street, PO Box 607
Kearny, NJ 07032-0607 USA
Tel: 201.991.5330 Fax: 201.991.5870
www.LRultrasonics.com info@LRultrasonics.com