



L&R Manufacturing Company

577 Elm Street, P.O. Box 607, Kearny, New Jersey 07032-0607 USA

Phone: 201-991-5330, Fax: 201-991-5870

E-mail: info@LRultrasonics.com, www.LRultrasonics.com

FUEL OIL NOZZLES – HEATING

Carbon deposits and oil residue can foul the tiny apertures in fuel oil nozzles and interfere with their proper functioning. Ultrasonic Cleaning Systems from L&R can restore their usefulness. Simply-

1. Disassemble nozzles, place parts into separate compartments of Fuel Oil Nozzle Tray.
2. Place tray into half-full Auxiliary Pan containing L&R Hydro-Sonic Cleaning Solution Concentrate or Hydro-Sonic Cleaning Solution Concentrate Non-Ammoniated, diluted 1:7 parts water. Agitate or swish tray up and down to remove excess oil.
3. Remove tray -- drain.
4. Place into main tank containing the same dilution of Hydro-Sonic or Hydro-Sonic Non-Ammoniated Cleaning Solution Concentrate and cavitate for 20 minutes.
5. Remove and rinse with hot running water.
6. Dry and reassemble. (Dip in fuel oil for storage.)

Note: Clean only one tray at a time. DO NOT OVERLOAD. Change solution every 6-8 trays. Plastic nozzles can be cleaned the same way.

EQUIPMENT NEEDED:

Machines, Accessories*: 2014, Q140 or S140 Ultrasonic Cleaning System with Timer, Optional Heater**, Fuel Oil Nozzle Tray, Auxiliary Pan and Cover.

Solutions: Hydro-Sonic Cleaning Solution Concentrate (Product Code 201); or Hydro-Sonic Cleaning Solution Concentrate Non-Ammoniated (Product Code 110).

*Recommended Ultrasonic Cleaning System varies as to internal tank dimensions and volume of required cleaning.

**If used with Hydro-Sonic Cleaning Solution Concentrate Non-Ammoniated. Heater not available on Model 2014.