



L&R Manufacturing Company

577 Elm Street, P.O. Box 607, Kearny, New Jersey 07032-0607 USA

Phone: 201-991-5330, Fax: 201-991-5870

E-mail: info@LRultrasonics.com, www.LRultrasonics.com

TACHOGRAPH, ODOMETERS, SPEEDOMETERS

Removing greases, gum sediments and oil residues is easy with Ultrasonic Cleaning Systems and solutions from L&R. Simply-

1. Place instrument in Basket and place Basket into tank #1 containing #112 Ammoniated Ultrasonic Instrument Cleaning Solution or Power Nofome Instrument Cleaning Solution.
2. Cavitate 3-5 minutes.
3. Remove Basket and place into tank #2 containing Instrument Rinsing Solution.
4. Cavitate 3-5 minutes, drain and allow to air dry.

EQUIPMENT NEEDED:

Machines & Accessories*: Q280 or S280 Ultrasonic Cleaning System with Timer, Auxiliary Pan, Basket; or 7652 with Clean & Rinse Kit.

Solutions: #112 Ammoniated Ultrasonic Instrument Cleaning Solution (Product Code 188); Power Nofome Instrument Cleaning Solution (Product Code 185); Instrument Rinsing Solution (Product Code 194).

*Recommended Ultrasonic Cleaning System varies as to internal tank dimensions and volume of required cleaning.

APPLICATION BULLETIN #40